


1/2" AIR IMPACT WRENCH (Twin Hammer)



INDEX NO.	PARTS NO.	DESCRIPTION	Q'TY
1	RH4002TA01	C-Ring	1
2	RH4002TA02	Screw	4
3	RH4002TA03	Hammer Case	1
4	RH4002TA04	O-Ring	1
5	RH4002TA05	Bushing	1
6	RH4002TA06	Anvil Collar	1
7	RH4002TA07	O-Ring	1
8	RH4002TA08	Anvil	1
9	RH4002TA09	Hammer Pin	2
10	RH4002TA10	Hammer Cage	1
11	RH4002TA11	Hammer Dog	2
12	RH4002TA12	Front Gasket	1
13	RH4002TA13	Motor Housing	1
14	RH4002TA14	O-Ring	1
15	RH4002TA15	Ball Bearing	1
16	RH4002TA16	Front Plate	1
17	RH4002TA17	Front Plate Washer	1
18	RH4002TA18	Cylinder	1
19	RH4002TA19	Spring Pin	1
20	RH4002TA20	Rotor	1
21	RH4002TA21	Rotor Blade	8
22	RH4002TA22	Rear Plate Washer	1
23	RH4002TA23	Rear Plate	1
24	RH4002TA24	Ball Bearing	1
25	RH4002TA25	Reverse Valve	1
26	RH4002TA26	O-Ring	1

INDEX NO.	PARTS NO.	DESCRIPTION	Q'TY
27	RH4002TA27	Rear Gasket	1
28	RH4002TA28	Rear Cover	1
29	RH4002TA29	Screw	4
30	RH4002TA30	Steel Ball	1
31	RH4002TA31	Spring	1
32	RH4002TA32	Screw	1
33	RH4002TA33	Reverse Lever	1
34	RH4002TA34	Valve Block Gasket	1
35	RH4002TA35	Spring Pin	2
36	RH4002TA36	Turn Base	1
37	RH4002TA37	Screw	2
38	RH4002TA38	Exhaust Deflector	1
39	RH4002TA39	O-Ring	1
40	RH4002TA40	Hose Adaptor - 18NPT	1
41		Hose Adaptor - 19PT	
42	RH4002TA41	Trigger	1
43	RH4002TA42	O-Ring	1
44	RH4002TA43	Valve Stem	1
45	RH4002TA44	O-Ring	1
46	RH4002TA45	Valve Body	1
47	RH4002TA46	O-Ring	3
48	RH4002TA47	Retainer	1
49	RH4002TA48	Valve Spring	1
50	RH4002TA49	Spring Pin	2
51	RH4002TA50	Muffler	1

HIW-P04500T

Consumable parts No. 4, 6, 7, 12, 23, 28, 30, 36, 48